


MIP MOT FLEX ZERO

Motorized wall mount

Soporte suelo-pared motorizado



Installation manual

Manual de instalación



Manuale di installazione

Asennusopas


Manuel d'installation.

DIMASA


Education, Corporate & Rental Mounts





CONTENIDO/CONTENTS/CONTENUTO/SISÄLLYS/CONTENU:




HERRAMIENTAS NECESARIAS/TOOLS NEEDED/ATTREZZI NECESSARI/TARPEELLISET TYÖKALUT/OUTILS NÉCESSAIRES:



1






ALLEN M10




DIN 912 M10x20(x2)
DIN 125 D/10


2




3




DIN 7380 M10x20 (x4)
DIN 125 D/10



ALLEN M8





4




5

5 Different positions, 2 pieces per side




DIN 7380 M8x16 (x4)
DIN 125 D/10




ALLEN M8

6



DIN7380 M8

7



x4






DIAGRAMA ELÉCTRICO DEL MOTOR / ELECTRICAL DIAGRAM OF THE LIFTING SYSTEM / DIAGRAMMA DELL'IMPIANTO ELETTRICO DI SOLLEVAMENTO / NOSTOJÄRJESTELMÄN TEKNINEN KAAVA / SCHÉMA ÉLÉCTRIQUE DU SYSTÈME DE REHAUSSE.



DIMASA
Education, Corporate & Rental Mounts

BARCELONA:
Pasatje Santa Rosa nº8-10, 08105 Sant Fost de Campcentelles (Barcelona) Tel: +34934620604 / +34916169688
MADRID:
c/ Parque Ferial nº 11, Pol. Ind. Urtinsa II, 28923 Alcorcón (Madrid)
Tel.: +34 91 616 96 88